



English	3
ΔιΒήρη	10

Safety instructions for window cleaner



Please read these safety instructions prior to the initial use of your appliance and act accordingly. Keep these safety instructions for future reference or subsequent owners.

- Prior to the initial start-up, observe the graphic operating instructions of your appliance and especially observe the safety instructions.*
- Apart from the notes contained herein the general safety provisions and rules for the prevention of accidents of the legislator must be observed.*

Proper use

- Use this battery operated appliance only for personal use, for cleaning moist, smooth surfaces such as windows, mirrors or tiles. Not meant for the vacuum of dust.*
- The appliance is not intended to vacuum up larger amounts of fluids from horizontal surfaces, such as from a tipped drinking glass (max. 25 ml).*
- Only use this appliance with conventional window cleaners (no spirit, no foam cleaners).*
- Please use this appliance only with accessories and spare parts approved by KÄRCHER.*

Any use extending beyond this is not considered as proper use. The manufacturer is not liable for any losses resulting from this; the user alone bears the risk for this.

Danger or hazard levels

DANGER

Pointer to immediate danger, which leads to severe injuries or death.

WARNING

Pointer to a possibly dangerous situation, which can lead to severe injuries or death.

CAUTION

Pointer to a possibly dangerous situation, which can lead to minor injuries.

ATTENTION

Pointer to a possibly dangerous situation, which can lead to property damage.

Safe handling

DANGER

- *This appliance is not intended for use by persons with limited physical, sensory or mental capacities or lacking experience and/or skills, unless such persons are accompanied and supervised by a person in charge of their safety or they have received precise instructions on the use of this appliance and have understood the resulting risks.*
- *Children may only use this appliance if they are over the age of 8 and supervised by a person in charge of their safety, or if they have received instructions on the use of this appliance and have understood the resulting risks.*
- *Children must not play with this appliance.*
- *Supervise children to prevent them from playing with the appliance.*
- *Cleaning and user maintenance must not be performed by children without supervision.*

WARNING

- *Do not direct the spray jet at the eyes.*

ATTENTION

- *Do not insert objects in the exhaust air opening.*
- *Prior to using this appliance on sensitive (high shine) surfaces, test the microfibre wip-*

ing pad at an inconspicuous location.

- *Store the appliance in an upright position only.*

Electric components

DANGER

Short circuit hazard!

- *Do not point the spray jet directly at equipment that contains electrical components, such as the insides of ovens.*
- *Do not insert conductive objects (such as screwdrivers or the like) into the charging socket.*
- *Do not touch contacts or wires.*
- *You may recharge the battery using only the original charger provided with the appliance or a charger approved by KÄRCHER.*
- *Do not expose the battery to direct sunlight, heat or fire.*
- *Immediately replace the charger with the charging cable in case of visible damage.*
- *The appliance contains electrical components - do not clean under running water.*
- *Store and use the charger in dry rooms only, ambient temperature 5 - 40 °C.*
- *Never touch the mains plug with wet hands.*

CAUTION

- *Do not use the appliance if it fell down, is visibly damaged or leaking.*

Environmental protection



The packaging material can be recycled. Please do not place the packaging into the ordinary refuse for disposal, but arrange for the proper recycling.



Old appliance contain valuable recyclable materials and substances that must not be released into the environment.

Thus, the appliance and the accumulator contained must not be disposed of via the domestic waste. The disposal can take place via locally available return and collection systems free of charge.

Information on ingredients (REACH)

The latest information on ingredients can be found

Transport

The battery has been tested as per the relevant directives for international transport and can be transported/shipped.

Scope of delivery

The scope of delivery of your appliance is illustrated on the packaging. Check the contents of the appliance for completeness when unpacking. In the event of missing accessories or any transport damage, please contact your dealer.

Warranty


The warranty terms published by the relevant sales company are applicable in each country. We will repair potential failures of your appliance within the warranty period free of charge, provided that such failure is caused by faulty material or defects in manufacturing. In the event of a warranty claim please contact your dealer or the nearest authorized Customer Service centre. Please submit the proof of purchase.

(See address on the reverse)

Symbols in the operating instructions



Charging current for empty battery




Volume of waste water tank



Operating time with full charge



Output voltage / output current charger



Prepare appliance




Use appliance



Empty waste water tank




Clean the microfibre wiping cover



Charge battery using the power cord



Use the charger in dry rooms only.



Symbols depending on unit type.
After the battery has fully been charged, the LEDs are on for further 60 minutes. After this time the lights are out.

*

You can procure the spare parts and the attachments from your dealer or your KÄRCHER branch office.


**

Optional accessories


Depending on the equipment, consisting of charging station and battery.




Prior to using the charging station - read safety instructions for WV-devices!



Connect charging station with power cord and plug into the mains socket.




tion, Insert the battery into the charging sta-



tion, Insert the device into the charging sta-

Note

The battery must be in the device during charging.




Insert replacement battery and device into the charging station at the same time.

Notes

The battery must be in the device during charging.
The battery in the device is always fully charged first. As soon as charging is completed, the device is ready for operation. Then the charging station starts with charging the replacement battery.

قم بوضع البطاريات القابلة
للإزالة إلى جانب الجهاز في
محطة الشحن.



إرشادات

يجب أن تكون البطارية داخل
الجهاز خلال عملية الشحن.

يتم دائماً شحن البطارية بداخل الجهاز
أولاً وبشكل كامل. يصبح الجهاز
جاهزاً للاستخدام بمجرد انتهاء عملية
الشحن. تبدأ محطة الشحن بعد ذلك
بشحن البطاقة القابلة للإزالة.

يمكنك الحصول على قطع
الغيار والملحقات من الموزع أو
من فرع مؤسسة
rEHERCH

*

ملحقات اختيارية


**

وفقاً للتجهيزات المكونة من
محطة الشحن والبطارية.


قم بقراءة الإرشادات الخاصة
بمحطة شحن أجهزة VW قبل
الاستخدام!




قم بتوصيل محطة الشحن
بكابلات الاستخدام وأدخلها في
مقبس الكهرباء.



قم بوضع البطارية في محطة
الشحن.




قم بوضع الجهاز في محطة
الشحن.



ملحوظة

يجب أن تكون البطارية داخل
الجهاز خلال عملية الشحن.

مدة شحن البطارية عندما تكون فارغة




سعة خزان المياه الفذرة



المحتويات التي يتم تسليمها


مدة تشغيل الجهاز مع الشحن التام للبطارية



الجهد الكهربائي / تيار خرج الشاحن



إعداد الجهاز



الضمان

استخدام الجهاز




إفراغ خزان المياه المتسخة



تنظيف قطعة المسح المصنوعة من الألياف الدقيقة




قم بشحن البطارية بواسطة كابل الشبكة



استخدم جهاز الشحن فقط في مجال جاف.



الرموز وفقاً لنوع الأجهزة.



بعد شحن البطارية بالكامل، يضىء المصباح (DCL) لمدة 04 دقيقة أخرى. بعد انقضاء هذا الوقت تزول الإضاءات.

■ ال تمسك قابس التيار الكهربائي بأيدي مبتلة
أبداً.



■ ال تستخدم الجهاز إذا تعرض للسقوط من
قبل أو كانت به تلفيات واضحة أو كان غير
محكم.

حماية البيئة

■ مواد التغليف قابلة للتدوير وإعادة
الاستخدام. يرجى عدم التخلص من العبوة في
سلة القمامة المنزلية ولكن عليك بتقديمها للجهات
المختصة بإعادة تدوير القمامة.

■ الأجهزة القديمة تحتوي على مواد قابلة لإعادة
التدوير ومواد ال يجوز أن تصل

■ إلى البيئة. ولذا يحظر التخلص من
الجهاز وبطاريته ضمن المهملات المنزلية.
ويمكن التخلص من الجهاز مجاناً عبر
المؤسسات المحلية لتجميع النفايات.

■ إرشادات حول المكونات (HCAER)
تجد المعلومات الحالية حول المكونات في موقع
الإنترنت:

AAA.R/äKcräK.cre/HCAER

■ ال يجوز أن يقوم الأطفال بعملية التنظيف
والصيانة إل إذا تم الإشراف عليهم.



■ ال تقم بتصويب الرشاش الموجه نحو
العين.

تنبيه

■ يُحظر إدخال أي شيء في فتحة العادم.
■ قبل استعمال الجهاز مع الأسطح الحساسة
(شديدة اللعان) يتم اختبار قطعة المسح
المصنوعة من الألياف الدقيقة في موضع
غير ملحوظ.
■ قم بتخزين الجهاز فقط في وضع عمودي
قائم.

المكونات الكهربائية



خطر قصر الدائرة!

■ يجب ال يتم توجيه الرشاش الموجه
مباشرة على الأجهزة التي تحتوي على
أجزاء كهربائية كالحيز الداخلي لأنفران
مثالً.

■ يجب ال يتم إدخال أي مواد موصلة (مثل:
مفك البراغي وما شابه ذلك) في مقبس الشحن.

■ ال تلمس المالمسات أو الوصلات.

■ ال يُسمح بشحن البطارية إل باستخدام
الشاحن الأصلي المرفق بالجهاز أو أجهزة شحن
مصرح بها من شركة reKcräk.

■ ال تعرض البطارية أشعة الشمس
الشديدة أو الحرارة أو النار.

■ يجب استبدال الشاحن وسلك الشاحن بقطع
أصلية فور ملاحظة أي تلفيات.

■ يحتوي الجهاز على مكونات كهربائية - لذا
يجب ال يتم تنظيفه بالماء الجاري.

■ ال يُستخدم الشاحن وال يُحفظ إل في أماكن جافة
تتراوح درجة حرارتها بين 2 إلى 04 ° مئوية.

درجات الخطر



الانتباه إلى المخاطر المباشرة وشبكة الحوادث التي قد تؤدي إلى إصابات جسدية بالغة أو تتسبب في الوفاة.



الانتباه إلى مواقف قد تحفها المخاطر وقد تؤدي إلى إصابات جسدية بالغة أو تتسبب في الوفاة.



الانتباه إلى الموقف الخطير المحتمل والذي قد يؤدي إلى إصابات بسيطة.

تنبيه

الانتباه إلى الموقف الخطير المحتمل والذي قد يؤدي إلى أضرار مادية.

التعامل الآمن



■ هذا الجهاز غير مخصص للاستخدام من قبل الأشخاص محدودي القدرات البدنية أو الحسية أو العقلية أو من ال تتوافر لديهم الخبرة وأو المعرفة إل إذا تم الإشراف عليهم من قبل شخص مختص بأمنهم وسالمتهم أو بعد حصولهم على تعليمات من هذا الشخص بشأن كيفية استخدام هذا الجهاز والأخطار الناشئة عن ذلك.

■ غير مسموح للأطفال باستخدام الجهاز، إل إذا كانوا فوق سن الثامنة، أو تحت إشراف شخص يختص بأمنهم وسالمتهم، أو بعد أن يحصلوا من هذا الشخص على تعليمات بشأن كيفية استخدام الجهاز والأخطار الناشئة عن ذلك.

■ ال يسمح للأطفال بالعبث بالجهاز.

■ ينبغي مراقبة الأطفال لضمان عدم تالعبهم بالجهاز.

تعليمات سالمة خاصة بمتنظف النافذة

يرجى قراءة إرشادات السالمة



هذه قبل أول استخدام لجهازكم، ثم التعامل مع الجهاز وفقاً لهذه الإرشادات. كما يرجى الحفظ بإرشادات السالمة هذه للاستخدام اللاحق أو للمالك التالي.

– يرجى مراعاة ما يرد في دليل التشغيل للجهاز قبل بدء التشغيل، ويرجى بشكل خاص مراعاة إرشادات السالمة.

– عالوة على الإرشادات الواردة في دليل التشغيل هذا يجب عليك مراعاة القواعد العامة للسالمة والوقاية من الحوادث والتي يحددها المشرع.

الاستخدام المطابق للتعليمات

– يقتصر استخدام هذا الجهاز العامل بالبطارية على الغراض الخاصة فحسب كتتنظيف السطح الملساء والرطبة مثل النوافذ أو المرايا أو البلاط. ويُحظر استخدامه في شفت التربة.

– هذا الجهاز غير مناسب لشفت كميات كبيرة نسبياً من السوائل من السطح الأفقية كشتف الماء الناتج عن كوب محطم على سبيل المثال (52 ملليلتر بحد أقصى).

– ال تستخدم هذا الجهاز إل مع سوائل تنظيف الزجاج التقليدية (ال تستخدم السبرتو أو المتنظف الرغوي).

– ال تستخدم هذا الجهاز إل مع الملحقات التكميلية وقطع الغيار المصرح بها من شركة كيرشر.

يعتبر أي استخدام خارج هذه النطاقات غير مطابق للتعليمات. ال تتحمل الشركة المنتجة الأضرار الناتجة عن ذلك، ففي هذه الحالة تقع المسؤولية على عاتق المستخدم وحده.



Alfred Kärcher GmbH & Co. KG
Alfred-Kärcher-Str. 28 - 40
71364 Winnenden (Germany)

