

#### FM RADIO PLAYBACK:

1. Change the mode to FM
2. Please insert the aux cable in its slot to act as an antenna for the FM Receiver.
3. In FM mode, short press the play/pause button. The speaker will automatically scan through the frequency and store the detected channels.
4. Press Forward or Rewind button to change the stored FM channel.

#### BATTERY CHARGING:

1. Put of the speaker. Use the provided charging cable to charge the device. While charging the LED light will turn LED.
2. Charge time is 1-2 hours, depending on The USB charger, Please provide a min. of 1A charging. Once fully charged the LED light will go of.
3. In order to prolong the life of the battery, please do not charge more than 8 hours.

#### NOTE:

- While operating wirelessly, the battery back up of the unit depends on the following factors: Volume level, Bass, Treble, Etc etc.
- The built-in rechargeable battery is not replaceable. Do not remove or replace it, do not throw in the trash or in fire.
- When cleaning the product, use a soft dry cloth. For more severe stains, please dampen the cloth with water only. Anything else has the chance of dissolving the paint or damaging the plastic.

Website: [www.artis.in](http://www.artis.in) | [www.artisstore.com](http://www.artisstore.com)

Customer care: +91-20-26113250/60

Email: [supportpune@artis.in](mailto:supportpune@artis.in)



MADE IN CHINA

# artis



## BT90 Portable BT Speaker

Handheld Music Box


USER MANUAL

# artis

Please read the user Manual carefully before operating the speaker.

#### FEATURES:

- Outdoor BT Speaker
- Clear sound, Dynamic Sound effect.
- A2DP Bluetooth. Wirelessly stream music from any Bluetooth device.
- Simple & Secure Pairing. User friendly operation
- 10 meters Operating Range.
- USB input, Micro SD Card Reader, FM Radio, Aux in
- Rechargeable 1500 mAh battery



#### CONTROL PANEL:

1. ON/OFF button
2. Micro SD Card slot
3. Charging Port
4. Previous song/ Volume Low
5. Next Song / Volume high
6. USB port
7. Aux-in
8. Playback Mode (Bluetooth, USB, Micro SD, FM, AUX)
9. Play/Pause

#### ACCESSORIES:

User Manual, Charging cable, Lanyard, Line in/ Aux cable

#### SPECIFICATIONS:

- BT Version: 2.1
- BT Range: 10 Meters
- Speaker Size: 2.1inch
- Speaker Output: 3W RMS
- Connectivity: USB, Micro SD Card, Aux, BT
- Power: 1500 Mah Lithium polymer battery.
- Charging: DC 5V 1A (USB-to-micro USB charging cable included)
- Size: 79.3(W) x 86.3(H) x 201.3(L)mm

#### BLUETOOTH PAIRING INSTRUCTIONS:

1. Turn ON the speaker. The blue LED will flash quickly and will beep once.
2. Activate Bluetooth pairing on your device and connect with Artis BT90. Once paired the Light will flash once and beep thrice.
3. Now that your device is paired, you can directly play music on the speaker.
4. Short press the forward or rewind buttons to change the tracks
6. Once paired, the Volume control of the devices has been synced. You can operate the same from the speaker control panel or from your device directly.

#### USB MEDIA OR MICRO SD CARD MEDIA PLAYBACK:

1. Turn ON the speaker. The blue LED will flash quickly and will beep once.
2. Insert USB media disk or Micro SD card into the slot, Stored music will play automatically and the LED light will be on constantly.

#### NOTE:

While the device is in BT mode, inserting a Micro SD card or USB Media device will change the mode to either of the 2 automatically. To change back to BT mode, please press the mode button

#### AUX-IN PLAYBACK:

1. Change the mode to aux in playback
2. Use the provided line-in cable and connect it to your aux device.
3. In aux mode, all functions will be controlled by the input device.