

Q1

How can I adjust the time of my watch at the time of switching Daylight Saving Time (Summer Time)?

A1

1. If the module no. of your watch is one of following 19 modules, please toggle DST setting (ON or OFF) in Timekeeping mode according to the page of Daylight Saving Time (Summer Time) setting in the operating instruction manual of your watch.
You can download the operating instruction manual directly by clicking the module no. in following.

Module no. (Representative models, Page as DST Setting)

2688 / 2638	(GW-500/MTG-900, Page 5)	
3054	(WV-58/59, Page4)	
3159	(GW-M5610, Page5)	
3194	(GLX-6900, Page1)	
3263	(GD-100, Page2)	
3299	(AE-1200, E-12)	
3410	(GW-9400, E-31)	
5081	(GA-100, Page1)	Video Operation Guide
5121	(GW-3000, Page3)	
5123	(EQS-500, Page2)	
5146	(GA-110, E-12)	Video Operation Guide
5161	(LCW-M100/WVA-M640, E-58)	
5208	(AQ-S800/S810, E-15)	Video Operation Guide
5229	(GA-120/200/201, E-12)	
5230	(AWG-M100, E-45)	
5255	(GA-150, E-12)	
5269	(SGW-500, E-19)	
5302	(GA-1000, E-14)	

2. If the module no. of your watch is one of following 2 modules, please toggle DST setting (ON or OFF) in Timekeeping mode according to the page of Daylight Saving Time (Summer Time) setting in the operating instruction manual of your watch, and also adjust the analog time according to the page of Analog time adjusting in the operating instruction manual of your watch because it does not work with DST setting.
You can download the operating instruction manual directly by clicking the module no. in following.

Module no. (Representative models, Page as DST Setting, Page as Analog time adjusting)

2747	(AW-80/81, Page1, Page1)
4778	(AW-590/591, Page2, Page2)

3. If the module no. of your watch is not above, please read an operating instruction manual of your watch.

You can download it clicking [here](#).



NOTE: Module number (four-digit or three-digit) is marked on the back cover of your watch.

Q2

What is the life of the solar cell and the rechargeable battery?

A2

Normally, the solar cell and rechargeable battery should be able to last as long as the watch.

Q3

How much do I need to expose the watch to light for charging?

A3

It depends on the model of your watch. Look at the back cover of your watch and find the three- or four-digit "module number". Next, click [here](#) for information about approximate required charging times for each module.

Q4

Are there any precautions to keep in mind when handling water resistant watch?

A4

The following applies to watches with WATER RESIST or WATER RESISTANT marked on the back cover.

“WATER RESIST” or “WATER RESISTANT” models

		Water resistance under daily use	Enhanced water resistance under daily use		
			5 atmospheres	10 atmospheres	20 atmospheres
Marking	On watch front or on back cover	NO BAR mark	5BAR	10BAR	20BAR
Example of daily use	Hand washing, rain	Yes	Yes	Yes	Yes
	Water-related work, swimming	No	Yes	Yes	Yes
	Windsurfing	No	No	Yes	Yes
	Skin diving	No	No	Yes	Yes

- Do not use your watch for scuba diving or other types of diving that requires air tanks.
- Watches that do not have WATER RESIST or WATER RESISTANT marked on the back cover are not protected against the effects of sweat. Avoid using such a watch under conditions where it will be exposed to large amounts of sweat or moisture, or to direct splashing with water.
- Even if a watch is water resistant, note the usage precautions described below. Such types of use reduce water resistance performance and can cause fogging of the glass.
 - Do not operate the crown or buttons while your watch is submersed in water or wet.
 - Avoid wearing your watch while in the bath.
 - Do not wear your watch while in a heated swimming pool, sauna, or any other high temperature/high humidity environment.
 - Do not wear your watch while washing your hands or face, while doing housework, or while performing any other task that involves soaps or detergents.
- After submersion in seawater, use plain water to rinse all salt and dirt from your watch.
- To maintain water resistance, have the gaskets of your watch replaced periodically (about once every two or three years).
- A trained technician will inspect your watch for proper water resistance whenever you have its battery replaced. Battery replacement requires the use of special tools. Always request battery replacement from your original retailer or from an authorized CASIO service center.
- Some water-resistant watches come with fashionable leather bands. Avoid swimming, washing, or any other activity that causes direct exposure of a leather band to water.
- Your water-resistant watch has been tested in accordance with International Organization for Standardization regulations.

“AIR DIVER’S 200M” or “DIVER’S WATCH 200M” models

- A diver’s watch is designed to withstand pressure up to 200 meters. Do not wear this watch at depths greater than the depth marked on it. It can be worn while skin diving, scuba diving, etc. Do not use a diver’s watch for deep diving (diving with a gas mixture) or at a depth greater than that indicated.

- The buttons of your watch can be operated while submerged. Do not operate the crown while the watch is submerged.
- After submersion in seawater, use plain water to rinse all salt and dirt from your watch.
- To maintain water resistance, be sure to have the gaskets of your watch replaced regularly (once every two years).
- A trained technician will inspect your watch for proper water resistance whenever you have its battery replaced. Battery replacement requires the use of special tools. Always request battery replacement from your original retailer or from an authorized CASIO service center.
- Your diver's watch has been tested in accordance with International Organization for Standardization regulations.