FAQ

1. <u>Download and install Brother iPrint&Scan - Windows or Macintosh computer</u>

Brother iPrint&Scan for PC/Mac provides access to printing, scanning, and workflow functionality. The supported function will vary based on your model's specifications and...

2. Add a printer driver - Windows 10

1. Download the Printer Driver or Add Printer Wizard Driver from http://support.brother.com . Click here for instructions on how to navigate to our downloads page....

3. <u>Default password for the Brother network card, firmware update,</u> BRAdmin, Web Based Management, or Remote Setup

Your Brother machine's default password for use configuring network settings, performing a firmware update, accessing BRAdmin, accessing Web Based Management, or accessing Remote Setup is...

4. Update the Firmware using the Firmware Update tool

Windows XP Users: The firmware update tool is no longer compatible with Windows XP. Please use a different operating system to update your firmware. Updating the firmware will delete some data from...

5. Google Chrome OS and Chromebook compatibility

We don't currently offer Google Chrome OS-compatible printer or scanner drivers. However, you may print to your machine using the Google Cloud printing feature. Refer to how to "Register and Print...

6. <u>Missing the option to print on both sides of the paper - Windows or Macintosh</u>

In the Brother printer driver, the option for 2-sided/Duplex print is typically located: Windows: On the Basic tab under 2-sided/Booklet or Duplex/Booklet . This location...

7. Macintosh macOS 10.15 Catalina - Compatibility

8. "Your PC Settings only let you install verified apps from the store" when attempting to install the Brother software

This issue is typically caused by a setting on your computer, which restricts third-party apps and software from being installed. If your computer is running Windows 10 S, by design, you...

9. Download and install Nuance PaperPort 14

You must be logged onto your computer as the administrator. Your machine must be connected to your computer and its software must already be installed before you can download and...

10. Open the Printers folder - Windows

Complete the following steps for your computer operating system: Windows XP or Server 2003 Click Start \rightarrow Control Panel \rightarrow Printers and Other Hardware \rightarrow View Installed Printers . To view the...

11. Compatibility with 5 GHz or Dual Band wireless network router

The standard specification for Dual Band routers allow devices connected to different bands (2.4 GHz or 5 GHz) to communicate. Your computer can be connected to the 5 GHz band network and be able to...

12. <u>Firewall ports needed to allow network communication with the Brother machine</u>

If a firewall is active on your computer, it may reject the necessary network connection needed for the network communication with the Brother machine. In order to resolve this issue, it...

13. Add a printer driver - Windows 7

1. Download the Printer Driver or Add Printer Wizard Driver from http://support.brother.com . Click here for instructions on how to navigate to our downloads page. ...

14. Scan using iPrint&Scan - Windows or Macintosh computer

Brother iPrint&Scan for PC/Mac provides access to printing, scanning and workflow functionality. Click here for instructions on how to download and install the Brother...

15. Scan a multi-page document into a single file PDF - ControlCenter4 Home Mode

You'll need to save your file as a PDF so that multiple pages are combined into a single document. The image below shows the ControlCenter4 in Home Mode. If you're using...

16. Set up Easy Scan to E-mail - Brother Apps

Easy Scan to E-Mail is a feature of Brother Apps that allows you to send scanned data via email directly from your Brother machine, without configuring any email server details. Security - Between...

17.2-sided (duplex) documents print upside down

If your duplexed documents are printing upside down, then you're likely using a generic printer driver. Many of the features of your Brother machine's printer are only available if you're using...

18. When printing from a computer, the data, status, or print indicator light flashes or the machine receives data but does not print

Generally this issue is caused by an interface problem or incorrect driver settings. Complete the following steps to troubleshoot this issue: 1. Verify the cable connection and cycle the...

19. Can't disable Two-Sided printing default - Macintosh

Depending on your operating system, Two-Sided printing may be enabled by default when using the Apple AirPrint printer driver. If a CUPS printer driver is available for your machine...

20. "Virus & threat protection - Unauthorized changes blocked" or "Controlled folder access blocked" when attempting to install or scan with ControlCenter4 or iPrint&Scan - Windows 10

You may receive a security pop up blocking scanning or the Brother software installation. This occurs when the Controlled Folder Access is enabled in Windows Defender for Windows 10...

21. When printing multiple copies or a multi-page document, only a single copy or page is printed - Windows

This issue is typically caused by a damaged Print Spooler or Print Processor, which are components of the operating system that control printing. As a work around, you may set the driver...

22. How to create a Brother PPD file for installation - Linux

We don't provide individual PPD files for all devices, however you can create a file for some machines. Your machine must have a Windows BR-Script Driver available for...

23. Download the "iPrint&Scan Push Scan Tool" - Macintosh

You may receive a notice to download and install the Brother iPrint&Scan Push Scan Tool when attempting to scan from the button on your Brother machine. This typically occurs...

24. How to install the software on a computer with no CD-ROM drive, if the CD has been lost, or if the CD won't run

The latest version of drivers, software, and manuals can be downloaded from the Brother Solutions Center at http://support.brother.com . Some third-party bundled applications are not available...

25. Add a TCP/IP port

Follow the steps for your operating system to add a TCP/IP port to the printer driver: Windows 10 a. Click \rightarrow All Apps \rightarrow Windows System \rightarrow Control Panel . b...

26. Software installation stalls, hangs, or freezes at Writing to the Registry

This issue is generally caused by a conflict with one of the items that start in the Operating System's boot sequence. To troubleshoot this issue, complete the following steps: Not all models are...

27. Random symbols, garbled text, garbage print, or prints unexpectedly

This issue can be caused by a wide variety of reasons. Complete the following steps based on your connection type: If this issue only occurs when printing from Adobe, click here for...

28. "The specified driver is invalid" or "Windows can't print due to a problem with the printer setup" when attempting to print - Windows 10

This is an issue with the Windows operating system that affects printing. For additional information about Microsoft's investigation of this issue, please click here to visit the Microsoft...

29. A USB cable is not included in the box with the Brother machine

A USB cable is not included with the purchase of your Brother machine. A list of components included with the machine is printed on the outside of the carton. Brother...

30. Wireless setup is requesting a WPS PIN to complete the setup

While attempting to set up the Brother machine on a wireless network, you may see a screen requesting a WPS PIN to complete the setup. This typically occurs if Wi-Fi Direct is enabled on...

31. "CC4-103" or "Unable to Write the File to the Destination Folder" - ControlCenter4

Before you begin: This issue can be caused by interference from security software. If you're using Bitdefender Antivirus, please make sure to add ControlCenter4 to the Trusted Applications and try to...

32. Google Cloud Print compatible models

There are two different ways to configure Google Cloud Print. Google Cloud Print 2.0 allows for easy setup and use on a computer connected to the same network as the Brother machine...

33. Scan using the ControlCenter4 - Home Mode

There are five scan options: Save , Print , Open with an Application , Send E-mail , and OCR . 1 PC Scan setting area 2 Image viewer 3 Save button 4 Print button 5 Open with an Application...

34. Attach, Email, and Print - Brother Apps

The Attach. Email and Print feature allows you to attach a document and email it to the Brother machine to be printed, without needing to install a driver. You simply attach a file to an outgoing...

35. "Manual Feed", "No Paper", "Load Paper" or "MP Tray" when printing from Microsoft Word or a similar application

This issue can occur for various reasons: - The paper source in the application is set to "Manual feed" or "MP tray". - The paper size...

36. Unable to print, scan, or use features of Brother iPrint&Scan - Apple iOS

The Brothe r iPrint&Scan app allows you to use features of your machine directly from your iPhone, iPod touch, iPad, or iPad mini. We recommend downloading the latest version of the...

37. "Difx driver package" error during installation

This can be caused by interference with third party anti-virus/firewall program, or a problem with the computer's operating system installation. - Please try...

38. "CC4-121" or set the default e-mail application for scanning with ControlCenter or the Scan key

The Scan to E-mail feature allows you to scan a document directly into your default e-mail application. If you haven't set a default e-mail application, you may receive error CC4-121-xxxxxxxx...

39. Manually find your wireless network's security settings (password)

We may be able to help you locate your wireless network's security settings if your computer is also connected to your network using a wireless connection. If you still can't find this...

40. "Cannot start Application Installer"

This issue may occur if the downloaded software installer's directory can't be accessed. To resolve this issue, you must download the software directly to a folder on the computer's Local...

41."User Intervention Required" when attempting to print

This error can occur if the print job enters the computer's Print Spooler, but then isn't sent to the printer. Complete the following steps to manually restart the print spooler: Not all...

42. Print using Apple AirPrint

1. Your Apple device must be running iOS 4.2 or later. The version can usually be found in the device's settings menu...

43. "CC4-006-0000" when scanning with ControlCenter4

To resolve this issue, complete the following steps: You must be logged into your computer with Administrator Rights. 1. If the computer is running any Antivirus, Firewall, Ransomware...

44. <u>Uninstall the Brother MFL-Pro Suite software, printer driver, and scanner driver - Windows</u>

Follow the instructions below to uninstall the Brother MFL-Pro Suite: 1. Close all other applications before beginning the uninstall process. You must be logged in with administrator...

45. How to open ControlCenter - Windows

If you see the CC4 icon in the task tray, double-click the icon. For Windows 7 or later, if you find the or button on the taskbar, click or button and...

46.Add a printer driver - Macintosh

If you have not already downloaded the Brother Printer Driver , you may do so by visiting http://support.brother.com . 1. Open Printers & Scanners . 2 . Click the + (plus) button located...

47. Brother Refresh FAQs

Signing up : - How much does Brother Refresh cost? -

48. "Object reference is not an instance of an object" when installing the Brother software

1. Make sure that you're logged in with Admin rights. 2. Make sure your computer's hidden files are visible: Not all models are compatible with all listed operating systems. To determine your...

49. Brother Print Service Plugin for Android

The Brother Print Service Plugin enables printing directly from your Android devices (Android 5.0 or later), to your Brother printer through a Wi-Fi network. The Brother machine must be connected to..