*Dear Customer,*

*Congratulations!*

*Welcome to the wonderful Prestige family! Thank you for choosing Prestige Roti Maker.*

*The Prestige Roti Maker has been carefully manufactured, tested and packaged so as to give you trouble-free performance.*

*After all, it is from Prestige – a trusted name in kitchenware for generations in India with customers countrywide.*

*We are sure your Prestige Roti Maker will add a touch of class and convenience to your kitchen!*

*Your Prestige Roti Maker comes with a one year (1 year) warranty.*

*Please read the instructions in the manual carefully, before use.*

# Important Safeguards

When using electrical appliances, basic safety precautions should always be followed including the following:

1. Read all instructions.
2. Make sure that your mains voltage corresponds to the voltage stated on the specification sticker of the Roti maker.
3. Always unplug from mains socket when not in use and before cleaning.
4. Do not immerse appliance, cord or plug in water or any other liquid.
5. Do not operate the Roti Maker with a damaged cord or plug, or in abnormal state. If its main cord is damaged, it must be replaced by the nearest Regional Service Centre/Authorised Service Centre.
6. Do not use any additional accessories that are not recommended by the company. It may result in fire, electric shock and/or personal injury.
7. Do not let the cord hang over edge of table or counter, or touch any hot surface.
8. To disconnect, remove plug from the wall outlet. Always hold the plug. Never pull the cord.
9. Do not use the appliance for uses other than its intended use and always place it in a dry area.
10. Do not leave the Roti Maker unattended while it is in operation.
11. Do not touch any hot surface. Use handle only.
12. Always place the appliance on a table or flat surface when operating.
13. There are no parts in your Roti Maker that are serviceable by the user. Unauthorized dismantling or servicing will void the product warranty.

14. Metal foil packages or utensils must not be placed on the Roti Maker as they may cause fire or electric shock.
15. Roti Maker must not be used near or below curtains and other combustible materials.
16. Close supervision is necessary when children are around.
17. The appliance should be strictly used for domestic purposes only.

## SAVE THESE INSTRUCTIONS

# KNOW YOUR ROTI MAKER

**Model : PRM 5.0**







1. Handle
2. Knob
3. Heater On Indicator
4. Power Indicator-Red
5. Upper Non-stick Cooking Plate
6. Lower Non-stick Cooking Plate
7. Upper Housing
8. Lower Housing

# Before First Use

- Read all instructions carefully and keep them for future reference.
- Remove all packaging.
- Clean the cooking plates by wiping with a sponge or cloth dampened in warm water. DO NOT IMMERSE THE UNIT IN WATER AND DO NOT POUR WATER DIRECTLY ONTO THE COOKING SURFACE.
- Dry with a cloth or paper towel.
- Lightly coat the cooking plates with a little cooking oil.

**NOTE: When your Roti Maker is heated for the first time, it may emit slight smoke or odor. This is normal with many heating appliances. This does not affect the safety of your appliance.**

# How To Use Your Prestige Roti Maker

- Close the Roti Maker and plug it into the wall outlet, you will notice that the red indicator light and the green indicator light will switch on, indicating that the roti maker has begun preheating.



- It will take approximately 3 to 5 minutes to reach cooking temperature. The red indicator light will remain on until you unplug your roti maker. When the green indicator light goes off, the Roti Maker is ready for use.
- Open the Roti Maker and make each piece of about 1 ½" diameter. Slightly flatten it and place it towards the hinges on the bottom plate of the roti maker as shown in the figure.



**Note:** To make soft rotis, add extra water than usual to the dough so that the dough is softer and stickier. Also set the dough aside for about 30 minutes to 1 hour before making rotis in the roti maker.

- Quickly and firmly press down and close the upper plate. Hold for a few seconds and open it immediately. You will see the dough ball has flattened enough for making roti. Leave the Roti Maker in open position for about 15-20 seconds.



- After about 20-25 seconds turn the roti and you will see air bubbles begin to appear on the top surface of the roti.
- Now turn the roti to the other side and very gently shut the upper plate. The roti will start puffing up and in a few seconds it is ready for serving.



- Once the roti is cooked, open the Roti Maker and carefully remove it from the Roti Maker with a non-metallic spatula.

  Never touch the cooking surface with sharp, pointed or metal objects. This could damage the non-stick surface.

  **Important: Every time you make roti, pre-heat the appliance until the green light goes off.**
- Once you are finished cooking, disconnect the plug from the wall outlet and allow the Roti Maker to cool in open position.
- This Roti Maker can be used for preparing other dishes also like Omelletes, Parathas, Theplas, Pancakes, Uthappams etc.

  while keeping the Upper Non Stick Cooking plate open.

## Cleaning And Maintenance

1. Disconnect the appliance from the mains outlet. Do not disassemble the Roti Maker for cleaning.
2. Let the appliance to completely cool down before you start cleaning.
3. Do Not immerse the Roti Maker in water or clean the appliance in running water.
4. Wipe the exterior surface with a soft, dry cloth. Never use scouring pads.
5. Clean the interior non stick surface with a soft damp cloth and then wipe it thoroughly with dry cloth.
6. Store the appliance in a cool dry place.
•7. The power cord can be wrapped around the bottom of base for storing.

## Technical Specifications

| Model | Wattage | Voltage |
|---|---|---|
| Prestige Roti Maker - PRM 5.0 | 900W | 230V 50 Hz |

# Warranty Card (Customer's Copy)

This page has to be treated as a full fledged warranty card and is required to be maintained by you. You will be required to produce this while claiming the service within the warranty period. In the unlikely event that a defect should develop in the Roti Maker during the period of this warranty, the product should be delivered at your cost to the Regional Service Centre/branches or Authorised Service Centre along with this warranty card.

Prestige Roti Maker: PRM 5.0

Date of purchase
Serial No:

Name: _____

Address: _____

_____

Dealer's Stamp & Address

# Terms Of Warranty

Prestige {hereinafter referred to as the Company} warrants to the purchaser of "Prestige Roti Maker", {hereinafter referred to as Prestige Roti Maker} that the said Prestige Roti Maker is free from all defects in material and workmanship. This warranty is valid for a period of one year from the date of original purchase, subject to the following terms and conditions:-

1) The warranty card is to be completed, signed by the dealer immediately on purchase.
2) The Prestige Roti Maker is only to be serviced by the Company Regional Service Centre or by its Authorised Service Centre (addresses listed in this manual).
3) The customer shall carry the Prestige Roti Maker to the nearest Company Regional Service Centre/Authorised Service Centre at his/her own cost and risk.
4) The Company shall make all endeavours/attempts to carry out the Service/Replacement under this Warranty at the earliest, but shall not be liable to do so within any specified time.
5) The Warranty will continue and remain in force only for the unexpired period of the original Warranty, in regard to the Repair/ Replacement of parts of the Prestige Roti Maker.
6) The Prestige Roti Maker shall be used strictly for domestic purposes in accordance with the user's manual.
7) The Company shall not be held liable for any accident, loss or damage (direct or indirect) to person or property caused by reason of:
    a) Repairs/Service attended by unauthorised service person.
    b) Over-loading/Misuse/abuse or/and negligence on the part of the person.
    c) Defects caused by improper/reckless use.
    d) Use of spurious spares/old, non-genuine spares.

e) Failure to comply with any safety precaution or maintenance tip suggested by the Company.

f) Original serial number is deleted/defaced or altered.

8) The Company shall not be responsible for any special consequential damages or loss arising directly or indirectly for any delay in the performance of this Warranty.

9) The Company reserves the right to retain any part or component at the Regional Service Centre/branches or Authorised Service Centre or at its workshop and shall effect Repairs/Replacement or parts or components at its sole discretion.

10) The non-stick coating is not covered under this warranty

11) This Warranty shall not in any case extend towards payment or any monetary consideration whatsoever, and shall be only limited to the product replacement.

12) Electrical parts are not covered under the warranty terms as they are subject to wear and tear. Replacement of these parts is chargeable.

13) Electrical appliances, wire points need regular check up by an authorised service person.

14) Electrical appliances are prone to voltage fluctuation risks, therefore precaution should be taken before use. Company shall not be responsible for any damage to electrical parts, arising out of this problem.

15) For repairs after the expiry of the warranty period, the authorised service centre will levy a charge (based on the MRP) for the component replaced.

16) The decision of the company is final in all cases of complaints.

17) Any complaints/disputes shall be within the jurisdiction of the Courts of Bangalore.

# REGIONAL SERVICE CENTRES

## HELPLINE NO. 3344 1111

| SOUTH ZONE | WEST ZONE | NORTH ZONE | EAST ZONE |
|---|---|---|---|
| **TTK Prestige Limited**<br>Old No. 17-A, New 18, Baliah Avenue (behind bank of India) Mylapore,<br>**CHENNAI-600 004**.<br><br>**TTK Prestige Limited**<br>AA 19, Siva Prakasm Salai, Next to Ukkira Kali Amman Koil, Backside of Mahatma Gandhi Centenary Vidayalaya, Anna Nagar, Tennur,<br>**TRICHY-620 017.**<br><br>**TTK Prestige Limited**<br>No. 110/5, Aruna Arcade, First Floor, Lalbagh Road, Sudhamanagar, BANGALORE - 560 027.<br><br>**TTK Prestige Limited**<br>Bombi & Sons Building, Damodar Collage Road, Comba, Margao,<br>**GOA -403 601.**<br><br>**TTK Prestige Limited**<br>XXXV /1953, 1954, Mareena, Bldg., M.G. Road, Ravipuram, Ernakulam,<br>**COCHIN : 682 016**.<br><br>**TTK Prestige Limited**<br>01-06-1973, Saeed Plaza, 3rd Floor Lakdi-Ka-Pul,<br>HYDERABAD-500 029.<br><br>**TTK Prestige Limited**<br>Sri Ramachandra Complex, D.No. 49-13-5, Ground Floor, Varun Bajaj Show Room Line, Benz Circle,<br>**VIJAYAWADA - 520 010**. | **TTK Prestige Limited**<br>2/B Wing, Ground Floor, Shruthi Sagar Co-Operative Housing Society, Old Police Quarters Lane, Andheri East, Opp Andheri Railway Station Near Bus Depot<br>**MUMBAI - 400 069**.<br><br>**TTK Prestige Limited**<br>Kanchan Heights, Old Big Bazaar Complex,<br>Block No 538, Sinhagad Road,<br>Near Bank Of Maharashtra, Parvati,<br>**PUNE - 411 009.**<br><br>**TTK Prestige Limited**<br>102, 103, Hassh Business Centre, 1st Floor Above ICICI Bank, Near Ankur School, Fathepura, Paladi<br>**AHMEDABAD - 380 007**.<br><br>**TTK Prestige Limited**<br>156, Devi Ahilya Marg, In front of Gujurat Tent House, Jail Road,<br>**INDORE - 452 001.** | **TTK Prestige Limited**<br>No.36, DLF Industrial Area,<br>Kirti Nagar, (Opp. Fun Cinema),<br>**NEW DELHI - 110015.**<br><br>**TTK Prestige Limited**<br>C/o Zurich India, B - 11,<br>Meerut Road, Industrial Area,<br>**GHAZIABAD-201009.**<br><br>**TTK Prestige Limited**<br>Plot No.438, Vill Basai Under Flyover, Near Railway Line, Main Basai Road, Gurgaon,<br>**HARYANA-122001.**<br><br>**TTK Prestige Limited**<br>S C O 88, 2nd floor,Sector 47 D<br>**CHANDIGARH-160047.**<br><br>**TTK Prestige Limited**<br>1st Floor, Near Katewa Chambers,<br>Near Shashtri Nagar Shopping Centre,<br>Pital Factory,<br>**JAIPUR - 302002.**<br><br>**TTK Prestige Limited**<br>F-1, First Floor, Rohit Bhavan,<br>B-Block - 4, Sapru Marg,<br>**LUCKNOW-226001.** | **TTK Prestige Limited**<br>30, Ist Floor, Ganesh Chandra Avenue,<br>**KOLKATTA-700 013**.<br><br>**TTK Prestige Limited**<br>C/o Ragini Enterprises,<br>Plot No.124, Road No.22,<br>Srikrishna Nagar,<br>**PATNA -800 001**.<br><br>**TTK Prestige Limited**<br>Plot No-104, Surya Vihar, Near By Sushil Motor (TVS Show Room), Opp Of BSNL Office,.<br>Link Road<br>**CUTTACK-753012.**<br><br>**TTK Prestige Limited**<br>Uttam Arcade, 2nd Floor, Opp Forest Office,<br>A.K.Azad Road, Rehabari,,<br>**GUWAHATI - 781 008.**<br><br>**TTK Prestige Limited**<br>C/O B P Kuntai (C&F), 501 Kadir Market,<br>Sakchi,<br>**JAMSHEDPUR-831 001.** |