



fitbit alta™



User Manual
Version 1.1

Table of Contents

Getting Started	1
What's in the box	1
What's in this document	1
Setting up your Fitbit Alta	2
Setting up your tracker on your mobile device	2
Setting up your tracker on your PC (Windows 10 only)	2
Setting up your tracker on your PC (Windows 8.1 and below)	3
Setting up your tracker on your Mac	3
Syncing your tracker data to your Fitbit account	4
Getting to know your Fitbit Alta.....	5
Wrist placement	5
Wrist choice and dominant hand	5
Putting on your tracker	5
Navigation	7
Tapping your tracker.....	8
Battery life and charging	9
Determining your current battery level	9
Charging your tracker.....	9
Care	10
Changing the wristband.....	10
Removing a wristband.....	10
Attaching a new wristband.....	11
Automatic Tracking with Fitbit Alta.....	12
Viewing all-day stats	12
Tracking sleep	12

Tracking a daily activity goal	13
Choosing a goal.....	13
Seeing goal progress.....	13
Tracking exercise	13
Tracking hourly activity.....	14
Using Silent Alarms	15
Receiving Call, Text, & Calendar Notifications	16
Calendar requirements	16
Enabling notifications	16
Viewing incoming notifications.....	17
Customizing your Fitbit Alta	18
Changing the clock face and orientation	18
Using Quick View.....	18
Updating your Fitbit Alta.....	19
Troubleshooting your Fitbit Alta	20
Fitbit Alta General Info & Specifications.....	21
Sensors, wireless, and haptic feedback	21
Materials	21
Battery	21
Memory	21
Display.....	21
Size	21
Environmental conditions.....	22
Help	22
Return policy and warranty	22
Regulatory & Safety Notices	23
USA: Federal Communications Commission (FCC) statement	23
Canada: Industry Canada (IC) statement.....	23

European Union (EU)	24
Australia and New Zealand.....	25
China	25
Wireless sync dongle	25
Alta	26
Mexico	26
Japan	26
Oman	26
Philippines	27
Serbia.....	27
Singapore.....	27
South Africa	27
South Korea	28
Taiwan.....	28
Wireless sync dongle	28
Alta.....	29
United Arab Emirates.....	29
Safety statement.....	30

Getting Started

Welcome to Fitbit Alta™, a customizable fitness tracker that's as versatile as your personal style. Take a moment to review our complete safety information at <http://www.fitbit.com/safety>.

What's in the box

Your Fitbit Alta box includes:



Fitbit Alta



Charging cable



Wireless sync dongle

The Fitbit Alta has two parts: the removable wristband and the display.

What's in this document

We get you started quickly by creating a Fitbit® account and making sure the tracker can synchronize the data it collects with your Fitbit dashboard. The dashboard is where you can analyze your data, see historical trends, set goals, log food and water, keep up with friends, and much more. As soon as you're done setting up your tracker, you're ready to start moving.

Next, we explain how to find and use the features that interest you and adjust your preferences. To find more information, tips, and troubleshooting, please browse our comprehensive articles at <http://help.fitbit.com>.

Setting up your Fitbit Alta

To make the most of your Alta, use the free Fitbit app available for iOS®, Android™, and Windows® 10 mobile devices. If you don't have a compatible mobile device, you can use a computer and fitbit.com instead, but keep in mind that a mobile device is required for call, text, and calendar notifications.

Setting up your tracker on your mobile device

The Fitbit app is compatible with more than 200 mobile devices that support iOS, Android, and Windows 10 operating systems.

To get started:

1. Make sure the Fitbit app is compatible with your mobile device by checking <http://www.fitbit.com/devices>.
2. Find the Fitbit app in one of these locations, depending on your device:
 - The Apple® App Store® for iOS devices such as an iPhone® or iPad®.
 - The Google Play™ Store for Android devices such as the Samsung® Galaxy® S5 and Motorola Droid Turbo.
 - The Microsoft® Windows Store for Windows 10 mobile devices such as the Lumia™ phone or Surface™ tablet.
3. Install the app. Note that you'll need an account with the applicable store before you can download even a free app such as Fitbit.
4. When the app is installed, open it and tap **Join Fitbit** to get started. You'll be guided through the process of creating a Fitbit account and connecting (pairing) your Alta to your mobile device. Pairing makes sure the tracker and mobile device can communicate with one another (sync their data).

Note that the personal information you're asked during setup is used to calculate your basal metabolic rate (BMR), which helps determine your estimated calorie expenditure. This information is private unless you go into your Privacy settings and opt to share age, height, or weight with Fitbit friends.

After setup you're ready to get moving.

Setting up your tracker on your PC (Windows 10 only)

If you don't have a mobile device, you can set up and sync your tracker on your Windows 10 PC using the same Fitbit app available for Windows mobile devices.

To get the app, click the Start button and open the Windows Store (called Store). Search for "Fitbit app." Note that if you've never downloaded an app from the store to your computer, you'll be prompted to create an account.

Open the app and follow the instructions to create a Fitbit account and set up your Alta. You can set up and sync wirelessly if your computer has Bluetooth®, otherwise you'll need to use the wireless sync dongle that came in the box with your Alta.

Setting up your tracker on your PC (Windows 8.1 and below)

If you don't have a compatible mobile device, you can set up your tracker with a computer and see your Fitbit stats on fitbit.com. To use this method you'll first install a free software application called Fitbit Connect that lets Alta sync its data with your fitbit.com dashboard.

To install Fitbit Connect and set up your tracker:

1. Go to <http://www.fitbit.com/setup>.
2. Scroll down and click the option to download.
3. When prompted, save the file that appears.
4. Double-click the file (FitbitConnect_Win.exe). The Fitbit Connect installer opens.
5. Click **Continue** to move through the installer.
6. When prompted, choose **Set up a New Fitbit Device**.
7. Follow the onscreen instructions to create a Fitbit account and connect your Alta.

Note that the personal information you're asked during setup is used to calculate your basal metabolic rate (BMR), which helps determine your estimated calorie expenditure. This information is private unless you go into your Privacy settings and opt to share age, height, or weight with Fitbit friends.

Setting up your tracker on your Mac

If you don't have a compatible mobile device, you can set up your tracker with a computer and see your Fitbit stats on fitbit.com. To use this setup method you'll first install a free software application called Fitbit Connect that lets Alta sync its data with your fitbit.com dashboard.

To install Fitbit Connect and set up your tracker:

1. Go to <http://www.fitbit.com/setup>.
2. Scroll down and click the option to download.
3. When prompted, save the file that appears.
4. Double-click the file (Install Fitbit Connect.pkg). The Fitbit Connect installer opens.
5. Click **Continue** to move through the installer.
6. When prompted, choose **Set up a New Fitbit Device**.
7. Follow the onscreen instructions to create a Fitbit account and connect your Alta.

Note that the personal information you're asked during setup is used to calculate your basal metabolic rate (BMR), which helps determine your estimated calorie expenditure. This information is private unless you go into

your Privacy settings and opt to share age, height, or weight with Fitbit friends.

Syncing your tracker data to your Fitbit account

Once you've set up and started using Alta, you'll need to make sure it regularly transfers (syncs) its data to Fitbit so you can track your progress, see your exercise history, earn badges, analyze your sleep logs, and more on your Fitbit dashboard. A daily sync is recommended but not required.

The Fitbit apps use Bluetooth Low Energy (BLE) technology to sync with your Fitbit tracker. Each time you open the app it syncs if the tracker is nearby, and it also syncs periodically throughout the day if you have the all-day sync setting enabled.

Fitbit Connect on a Mac® also uses Bluetooth for syncing (if available), otherwise you'll need to make sure your wireless sync dongle is plugged into the computer. Fitbit Connect on a PC requires that you plug in your wireless sync dongle. You can force Fitbit Connect to sync at any time or it will happen automatically every 15 minutes if:

- The tracker is within 30 feet of your computer.
- The computer is powered on, awake, and connected to the Internet.

Getting to know your Fitbit Alta

This section tells you how best to wear, navigate, and recharge your tracker. If you bought an accessory wristband, you'll also find instructions for taking off the original band and putting on a different one.

Wrist placement

Review these tips to make sure you're wearing your tracker correctly.


Wrist choice and dominant hand

For greater accuracy and ease of use, Alta needs to know which wrist you wear it on (right or left) and which hand you consider dominant (right or left). Your dominant hand is the one you usually write or throw with.


During setup you're asked to choose the wrist where you're going to wear Alta. Should you later decide to move Alta to the other wrist, change the Wrist setting. You can also change your dominant hand at any time with the Handedness setting. Both settings are found in the Account section of the Fitbit app.

Putting on your tracker


1. Place your Alta around your wrist. The top of the tracker is the side with the charging port. The top of the tracker should be on the outside or top of your wrist.





2. Align both ends of the wristband so they are directly overlapping each other with the clasp over the two holes that best fit your wrist.



3. Squeeze both the clasp and the wristband between your thumb and forefinger until you feel it snap into place.




You'll know your Alta wristband is securely fastened if both pegs on the clasp are fully inserted. Do not wear your Alta too tightly.



TIP: If you're having trouble, try securing the wristband off your wrist to get a feel for how it securely clasps and then try again on your wrist.

Navigation

Alta has an OLED tap display that can be oriented horizontally or vertically. You can choose from several clock faces, each with a unique design.




When you're not using Alta the display is off. To wake it up:

- Double-tap your tracker.
- Turn your wrist towards you. This behavior, known as Quick View, can be turned off in your tracker settings.

Single-tap to flip through your stats. Stats include steps taken, distance covered, calories burned, and active minutes.

Tapping your tracker

For best results, tap your tracker where the display meets the band as shown below. To wake up your tracker, double-tap it; to flip through your stats, single-tap it.




Alta doesn't respond to swipes; it must be tapped.

Battery life and charging

Your fully charged Alta has a battery life of up to 5 days. Note that battery life and charge cycles vary with use, settings, and many other factors. Actual results will vary.

Determining your current battery level

When you tap your Alta to flip through your stats, the first screen will show a low battery icon if your battery is low. If you see a critically low icon you'll be unable to flip through your stats.




Critically low battery

You can also check your battery level on your Fitbit dashboard.

Charging your tracker

To charge your Alta, plug the charging cable into the USB port on your computer or a UL-certified USB wall charger, then clip the other end into the port on the back of the Alta. The pins on the charging cable must be lined up with the charging port on the Alta and securely locked into place. You'll know the connection is secure when you see a battery icon on Alta's display.



Charging fully takes one to two hours. While the tracker charges, you can tap it to check the battery level. A fully charged tracker shows a solid battery icon. If you haven't set up your tracker yet, when you tap it you'll see a message directing you to <http://www.fitbit.com/setup>.

Care

It's important to clean and dry your Alta regularly. For instructions and more information see <http://www.fitbit.com/productcare>.


Changing the wristband

The wristband has two separate bands (top and bottom) that you can swap with accessory bands sold separately.


Removing a wristband

To remove the wristband:

1. Turn over your Alta and find the band latches—there's one on each end where the band meets the frame.
2. To release the latch, press down on the flat metal button on the strap.



3. Slide the band up to release it from the tracker.



4. Repeat on the other side.


If you're having trouble removing the band or if it feels stuck, gently move the band

back and forth to release it.

Attaching a new wristband

Before you attach a new wristband, first identify the top and bottom bands. The top band has notches in it and should be attached on the side closest to the charging port. The bottom band has a clasp on it.

To attach a band, slide it down on the end of the tracker until you feel it snap into place.



Automatic Tracking with Fitbit Alta

Your Alta tracks a variety of stats automatically whenever you're wearing it. Your tracker's latest data is uploaded to your Fitbit dashboard whenever you sync.

Viewing all-day stats

Tap your Alta to see these all-day stats:

- Steps taken
- Distance covered
- Calories burned
- Active minutes


Other stats captured by your tracker are available on your Fitbit dashboard, including:

- Hours slept and sleep patterns
- Hourly activity and stationary time
- Exercise like running, outdoor biking, elliptical, sports, and aerobic activities


Double-tap your Alta to wake it up. When you see the clock, tap to see each of your stats in turn. If you have an alarm set, you'll also see the next alarm time.



Steps



Distance



Calories



Active minutes

Alta starts tracking your stats for the next day at midnight based on your time zone. Though your stats reset to zero at midnight, the previous day's data is not deleted. That data will be captured in your Fitbit account when you next sync your tracker.

Tracking sleep

Alta automatically tracks the time you sleep and your movement during the night to help you understand your sleep patterns. To track sleep, simply wear your Alta to bed. By default you have a customizable sleep goal of 8 hours of sleep per night.

Sync your tracker when you wake up to see last night's sleep data on your Fitbit dashboard.

Tracking a daily activity goal

Alta tracks your progress towards a daily activity goal of your choice. When you reach your goal, the tracker vibrates and flashes in celebration.

Choosing a goal

By default your goal is 10,000 steps per day. You can change the goal to distance traveled, calories burned, or active minutes and select the corresponding value you prefer. For example, you may want to keep steps as your goal but change the target from 10,000 to 20,000 steps.

Seeing goal progress

A goal progress bar helps keep you motivated. The dots in the bar shown below indicate that you're more than halfway to your goal.



Tracking exercise

The SmartTrack™ feature automatically detects selected exercises and records the details in your exercise history.

By default, SmartTrack detects continuous movement at least 15 minutes in length. You can increase or decrease the minimum duration or disable SmartTrack for one or more exercise types.

For more information about customizing and using SmartTrack, see help.fitbit.com.

Tracking hourly activity

The Reminders to Move feature helps keep you active throughout the day for better health and fitness. If you haven't walked at least 250 steps in a given hour, at ten minutes before the hour you'll feel a vibration reminding you to walk. If you accumulate enough steps in time you'll see a congratulatory message.



You can find more information about your hourly activity and stationary periods on your Fitbit dashboard.

Using Silent Alarms

Alta can gently vibrate to wake or alert you with a silent alarm. You can set up to eight alarms to recur every day or on particular days of the week only. When the alarm goes off, simply double tap to dismiss.

For more information about customizing and using silent alarms, see help.fitbit.com.



Receiving Call, Text, & Calendar Notifications

Over 200 compatible iOS and Android mobile devices let you receive incoming phone call, text message, and calendar event notifications on your Alta. To determine whether your device supports this feature, go to <http://www.fitbit.com/devices>. Note that notifications aren't available with the Fitbit app for Windows.

Calendar requirements

Your tracker will show calendar events and any information sent from your calendar app to your mobile device. Note that if your calendar app does not send notifications to your mobile device, you won't receive notifications on your tracker.



If you have an iOS device, your Alta shows notifications from all calendars synced to the default iOS Calendar app. If you have a third-party calendar app that is not synced to your default app, you won't see notifications from that app.

If you have an Android device, your Alta shows calendar notifications from the calendar app you choose during setup. You can choose from the default Calendar app on your mobile device or several third-party calendar apps.

Enabling notifications

Before you turn on notifications in the Fitbit app, make sure that Bluetooth on your mobile device is turned on and that your mobile device is capable of sending notifications (often under Settings > Notifications).

For more information about making sure your mobile device permits notifications, see help.fitbit.com.

Call and text notifications are on by default. To turn on calendar notifications:

1. With your tracker nearby, on the Fitbit app dashboard, tap the Account icon (☰).
2. Tap the Alta tile.
3. Tap **Notifications** and turn on or off any combination of text, call, or calendar notifications.
4. Follow the onscreen instructions to connect (bond) your mobile device with your tracker.

After notifications are enabled, "Alta" appears in the list of Bluetooth devices paired to your mobile device.

Note: If this is your first time setting up notifications on your Android mobile device, for detailed instructions, see help.fitbit.com.

Viewing incoming notifications

If your tracker and mobile device are within 30 feet of each other, a call, text message, or calendar event causes the tracker to vibrate and the notification to appear on Alta's display. If the display is off, turn your wrist towards you or double-tap to wake it up. The notification is only visible for one minute.

For phone calls, the notification scrolls three times with the name or number of the caller.



For text messages and calendar events, the notification scrolls once.



The character limit for notifications is 40. Note that all notifications are shown horizontally, even if your clock orientation is normally vertical.

Customizing your Fitbit Alta

This section explains how to adjust your display and modify certain tracker behaviors.

Changing the clock face and orientation

Alta comes with several clock faces available in horizontal and vertical styles.

You can change your clock face using the Fitbit app or the [fitbit.com](https://help.fitbit.com) dashboard. For more information, see help.fitbit.com.

Note that all notifications and reminders are shown horizontally, even if your clock orientation is vertical.

Using Quick View

To preserve battery your screen turns off when not in use. It wakes up automatically when you turn your wrist towards you (known as Quick View), or you can wake it up by double tapping your tracker.

For more information about turning Quick View on or off, see help.fitbit.com.

Note that Quick View works best when wearing the tracker properly as described in [Error! Reference source not found.](#)

Updating your Fitbit Alta

Free feature enhancements and product improvements are occasionally made available through firmware updates. We recommend keeping your Alta up to date.

You'll be notified in the Fitbit app when an update is available. After you start the update, you'll see a progress bar on your tracker and in the Fitbit app until the process is complete, followed by a confirmation message.

Note that updating your Alta takes several minutes and may be demanding on the battery. For this reason, we recommend plugging your tracker into the charging cable before updating.

Troubleshooting your Fitbit Alta

If you experience one of the following problems, it may be fixed by restarting your tracker:

- Not syncing despite successful setup
- Not responding to taps
- Unresponsive despite being charged
- Not tracking your steps or other data

Note: Restarting your tracker reboots the device but does not delete any data.

To restart your tracker:

1. Plug your charging cable into a USB port on your computer.
2. Insert the other end into the port on the back of your Alta. Your Alta will begin charging.
3. Press the button on your charging cable three times within eight seconds, briefly pausing between presses. The button is on the end of the charging cable that is plugged into the computer.

Eight seconds after the first button press, you'll see the Fitbit logo on the display. This is your indication that the tracker restarted.

4. After you see the logo you can unplug Alta from the charging cable.

For additional troubleshooting or to contact Customer Support, see <http://help.fitbit.com>.

Fitbit Alta General Info & Specifications

Sensors, wireless, and haptic feedback

Your Fitbit Alta contains the following sensors and motors:

- A MEMS 3-axis accelerometer, which tracks your motion patterns
- A Bluetooth 4.0 radio transceiver
- A vibration motor, which allows Alta to vibrate for alarms, goals, notifications, and reminders

Materials

The wristband that comes with Alta is made of a flexible, durable elastomer material similar to that used in many sports watches. It does not contain latex. Accessory wristbands are available in genuine leather and stainless steel.

The clasp and housing on Alta are made of surgical-grade stainless steel. While all stainless steel contains traces of nickel and can cause an allergic reaction in someone with nickel sensitivity, the amount of nickel in all Fitbit products meets the European Union's stringent Nickel Directive.

Battery

Alta contains a rechargeable lithium-polymer battery.

Memory

Alta stores detailed minute-by-minute information for five days, sleep data for seven days, SmartTrack data for two days, and summary totals for 30 days.

Stored data consists of steps taken, distance traveled, calories burned, active minutes, hourly activity, SmartTrack exercise, and sleep.

Display

Alta has an OLED tap display.

Size

Wristband sizes are shown below. Note that accessory wristbands sold separately may vary slightly. Metal wristbands are one size fits all.

Small wristband	Fits a wrist between 5.5 and 6.7 inches in circumference
Large wristband	Fits a wrist between 6.7 and 8.1 inches in circumference
Extra large wristband	Fits a wrist between 8.1 and 9.3 inches in circumference

Environmental conditions

Operating Temperature	14° to 113° F (-10° to 45° C)
-----------------------	----------------------------------

Non-operating Temperature	-4° to 140° F (-20° to 60° C)
---------------------------	----------------------------------

Water Resistant	Splash proof.
-----------------	---------------

Maximum Operating Altitude	30,000 feet (9,144 m)
----------------------------	--------------------------

Help

Troubleshooting and assistance for your Fitbit Alta can be found at <http://help.fitbit.com>.

Return policy and warranty

Warranty information and the fitbit.com return policy can be found online at <http://www.fitbit.com/returns>.

Regulatory & Safety Notices

Model Name: FB406

USA: Federal Communications Commission (FCC) statement

This device complies with FCC part 15 FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference and
2. This device must accept any interference received, including interference that may cause undesired operation

FCC Warning

Changes or modifications not approved by Fitbit, Inc. could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device meets the FCC requirements for RF exposure in public or uncontrolled environments.

FCC ID: XRAFB406

Canada: Industry Canada (IC) statement

This device meets the IC requirements for RF exposure in public or uncontrolled environments.

Cet appareil est conforme aux conditions de la IC en matière de RF dans des environnements publics ou incontrôlée

IC Notice to Users in accordance with RSS GEN:

This device complies with Industry Canada license exempt RSS standard(s).
Operation is subject to the following two conditions:

1. this device may not cause interference, and
2. this device must accept any interference, including interference that may cause undesired operation of the device

Cet appareil est conforme avec Industrie Canada RSS standard exempts de licence (s). Son utilisation est soumise à Les deux conditions suivantes:

1. cet appareil ne peut pas provoquer d'interférences et
2. cet appareil doit accepter Toute interférence, y compris les interférences qui peuvent causer un mauvais fonctionnement du dispositif

IC ID: 8542A-FB406

European Union (EU)

Simplified EU Declaration of Conformity

Hereby, Fitbit, Inc. declares that the radio equipment type Model FB406 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

<http://www.fitbit.com/safety>.

Déclaration UE de conformité simplifiée

Fitbit, Inc. déclare par la présente que les modèles d'appareils radio FB406 sont conformes à la Directive 2014/53/UE. Les déclarations UE de conformité sont disponibles dans leur intégralité sur le site suivant: www.fitbit.com/safety.

Dichiarazione di conformità UE semplificata

Fitbit, Inc. dichiara che il tipo di apparecchiatura radio Modello FB406 è conforme alla Direttiva 2014/53/UE. Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: www.fitbit.com/safety.

Vereinfachte EU-Konformitätserklärung

Fitbit, Inc. erklärt hiermit, dass die Funkgerätypen Modell FB406 die Richtlinie 2014/53/EU erfüllen. Der vollständige Wortlaut der EU-Konformitätserklärungen kann unter folgender Internetadresse abgerufen werden: www.fitbit.com/safety.

Declaración UE de Conformidad simplificada

Por la presente, Fitbit, Inc. declara que el tipo de dispositivo de radio Modelo FB406 cumple con la Directiva 2014/53/UE. El texto completo de la declaración de conformidad de la UE está disponible en la siguiente dirección de Internet: www.fitbit.com/safety.



Australia and New Zealand



R-NZ

China



Wireless sync dongle

部件名称	有毒和危险品					
Dongle Model FB150	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴化苯 (PBB)	多溴化二苯醚 (PBDE)
表带和表扣	O	O	O	O	O	O
电子	X	O	O	O	O	O
本表格依据 SJ/T 11364 的规定编制						
O: 表示该项目中涉及的所有物料, 其包含的有害物质的含量低于 GB/T 26572. 标准的限制要求.						
X: 表示该项目中涉及的所有物料中至少有一种, 其包含的有害物质的含量高于 GB/T 26572. 标准的限制要求.						

Alta


部件名称	有毒和危险品					
Alta Model FB406	铅 (Pb)	水银 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴化苯 (PBB)	多溴化二苯醚 (PBDE)
表带和表扣	O	O	O	O	O	O
电子	X	O	O	O	O	O
本表格依据 SJ/T 11364 的规定编制 O: 表示该项目中涉及的所有物料, 其包含的有害物质的含量低于 GB/T 26572. 标准的限制要求. X: 表示该项目中涉及的所有物料中至少有一种, 其包含的有害物质的含量高于 GB/T 26572. 标准的限制要求.						

Mexico



IFETEL: RCPFIFB15-2258

Japan



201-152821

Oman

OMAN-
TRA/TA-
R/3029/16
D090258

Philippines




Serbia



Singapore



South Africa



South Korea

클래스 B 장치 (가정 사용을 위한 방송 통신 기기) : EMC 등록 주로 가정용 (B 급)으로하고, 모든 지역에서 사용할 수 있습니다
연율이 장치.

“ 해당 무선설비는 전파혼신 가능성이 있으므로 인명안전과 관련된 서비스는 할 수 없습니다 ”



- 사용 주파수 (Used frequency): 2402 MHz-2480 MHz
- 채널수 (The number of channels): 40
- 공중전계강도 (Antenna power): -7.4dBi
- 변조방식 (Type of the modulation): GFSK
- RF 출력 (RF Output): 3.6dBm
- 안테나 유형 (Antenna Type): Monopole Antenna (Stamped metal)
- 작동 온도 범위 (Operating Temperature Range): -10°C ~ 50°C
- 동작 전압 (Operating voltage): DC 3.7V

KC 인증서 정보 KC Certificate Information

- 1) 장비 이름 Equipment name: 저전력 무선 장치 (무선 데이터 통신의 무선 장치)
Low power radio equipment (wireless devices of wireless data communications)
- 2) 모델 이름 Model name: FB406
- 3) 인증서 번호 Certificate number : MSIP-CMM-XRA-FB406
- 4) 회사 이름 Company Name : Fitbit, Inc.
- 5) 제조업 자 Manufacturer: Fitbit, Inc. / 중국 (China)
- 6) 제조 일자 Manufactured Date: 201_

Taiwan

Wireless sync dongle



CCAJ15LP1150T4

Alta



CCAJ15LP6230T1

注意！

依據 低功率電波輻射性電機管理辦法

第十二條 經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

第十四條

低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。

前項合法通信，指依電信法規定作業之無線電通信。

低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

United Arab Emirates

TRA
REGISTERED
NO:
ER44211/16

DEALER NO:
DA35294/14

Safety statement

This equipment has been tested to comply with safety certification in accordance with the specifications of EN Standard: EN60950-1:2006 + A11:2009 + A1:2010 + A12: 2011 + A2:2013.

